




ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts.
2. Drill the two holes and insert plastic anchor (A) in each.
3. Insert the self-tapping screws (B) into holes and tighten unit.
Place mounting plate (C) on wall level.
4. Place shade (E) over socket (D) and secure it with socket ring (F).
5. Install the bulb into the socket (bulb not included).

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.